

Reusing electroporation cuvettes

- 1) Wash the cuvette with water
- 2) Add 1 ml 30% HNO_3 and wait 1 hr.
This is a hazardous chemical, use a lab coat, eye protection, and gloves.
- 3) Wash with water extensively.
- 4) Fill the cuvette with 95% EtOH and wait 24 hrs.
- 5) Remove the ethanol and dry under vacuum. Alternately you can just let all the ethanol evaporate in a laminar flow hood.